






Instruction Sheet # 10014972

Caster Kit Assembly Instructions “L” Unit



Note: Slatwall shown in this picture is optional

Parts:




Base from
“L” Unit
(B)



Fastening Casters onto Base:

1


B



Turn base (B) upside down. Slide caster (cA) into slot and line up holes.




2



Using bolts (cB) and nuts (cD), fasten casters to base.

cA

B



cE

If the unit will be positioned against a "T" unit: Attach Lock Adapter Channel (cE) to base as shown on the opposite side as the casters using the innermost bolt holes.

Note: Lock Adapter Channel is not used if the unit will be standing alone.

3

Finish assembling the unit starting with Step 3 of the Basic "L" Unit Assembly Instructions.



One Pickroy Rd.
Jasper, GA. 30143
(800)-334-1766