



REVISION HISTORY			
REV	DESCRIPTION	DATE	BY
A	INITIAL RELEASE		



STEP 1. TILT PRICE TAG MOLDING AT AN ANGLE SHOWN IN (DETAIL A) AND LET REST ON TOP EDGE OF SHELF. PRESS FIRM AT THE BOTTOM EDGE OF THE MOLDING TO SNAP AND LOCK INTO PLACE .



STEP 2. INSTALL CLEAR PLASTIC RAIL IN THE SLOT OF THE MOLDING SHOWN IN (DETAIL B) AND PRESS DOWN TO SEAT THE PLASTIC RAIL SHOWN IN FIGURE 1 DETAIL C





FIGURE 1.



STEP 1. TILT PRICE TAG MOLDING AT AN ANGLE SHOWN IN (DETAIL A) AND LET REST ON TOP EDGE OF SHELF. PRESS FIRM AT THE BOTTOM EDGE OF THE MOLDING TO SNAP AND LOCK INTO PLACE . INSTALL SO THAT PRICE TAG MOLDING END IS TO THE INSIDE OF FLANGE OF SHELF AND NOTCH CLEARS THE SHELF SUPPORT SHOWN (DETAIL B).





FIGURE 1.

These designs are proprietary information, property of ROYSTON LLC. They shall not be copied or duplicated in any manner without prior written consent.	REF #	00000				
	SURFACE AREA	NEXT STEP				
	TRVL DIST	SOURCE				
		N/A				
Tolerance Unless Otherwise Noted .XXX = ± .015 .XX = ± .030 Angles = ± 1° Hole Dia. = ± .003	PART DESCRIPTION					
	INST,SHF,BSHF,FLAT,GUM,MINT,WIRE					
ENG	DRAWN BY	DATE	PART #			
EMW	EMW	9/18/2013	70009607	REV		
				A		





FIGURE 1



DETAIL A





FIGURE 3



GUM AND MINT/CANDY
SHELF PROFILE

STEP 2. INSTALL CLEAR PLASTIC RAIL IN THE SLOT OF THE MOLDING SHOWN IN FIGURE 3 AND PRESS DOWN TO SEAT THE PLASTIC RAIL SHOWN IN FIGURE 4 DETAIL C





FIGURE 2.



DETAIL B





FIGURE 4



DETAIL C